




# FACKELMANN®



## TWINDY

80092  
80093  
80097  
80096 CH  
80098 CH  
80099 CH



\*OFF = Oberkante fertiger Fußboden

\*OFF = Top edge of finished floor


1	2	3	4	5	6
4XBB81HDN0	Ø8	4BB8046X25	4SK3.0X120	4SL2872810	4SL0826910
1 x		2 x	4 x	16 x	4 x

**FACKELMANN®** GmbH + Co. KG

Sebastian-Fackelmann-Str. 6  
91217 Hersbruck • Deutschland  
FAX: 09151/811-294  
Servicetelefon: 09151/811-206  
servicebm@fackelmann.de  
www.fackelmann.com


VDE 0100-701  
IEC 60364-7-701!

MAX. 16 A  
230 V ~ 50Hz



DE: 4SL0834729

MAX. 10 A  
230 V ~ 50Hz




CH: 4SL0834791



Eine defekte Elektrobox ist vollständig durch eine neue Box zu ersetzen.

The trafo-box cannot be repaired and must be replaced.


1





1.1




1.2




1.3



1.4




1.5




2

2.1



2.2




**FACKELMANN®**

5BB0800932 S3 10/22




# Austausch der Türen Replacement of doors




1


1.1




1.2



1.3




1.4







2

2.1





2.2






Ersatzteil / replacement part  
2XFTM80093  
2RFTM80097  
2LFTM80097

2.3





2.4







**FACKELMANN®**

5BB0800932 S5 10/22



Dämpfung aktiv / attenuation on



Dämpfung inaktiv / attenuation off




**FACKELMANN®**

5BB0800932 S6 10/22


82960 nicht inklusive  
not included




1.1




b



1.2




1.2



3,5 x 13mm  
4RK3.5X131

4 x


1.3




3,5 x 13mm  
4RK3.5X131

2 x



1.3



1.4



1.4



**FACKELMANN®**


5BB0800932 S7 10/22



Austausch LED-Band/  
change of LED-stripe



80092/3/7

80096/8/9 CH




**Achtung:**  
Vor dem LED-Austausch Glasböden  
aus dem Schrank entfernen!  
**Attention:**  
Remove glass from the cupboard  
before changing the LED-stripe!

1




2

2.1




2.2




3


3.1



3.2



3.3




4


Ersatzteil/ replacement part



4.1




4.2



5

5.1



5.4



6

6.2

6.1



FACKELMANN®

5BB0800932 S9 10/22

